Lamp LED Flashing RED?
YES
Change lamp with part # A 1052-675-A
NO
StandBy LED flashing RED 5
YES
Does the Spark Gap fire when the set is turned on?
YES
Change lamp with part # A-1052-675-A
NO
Troubleshoot according to service manual.
NO
Check CN1602 on G1 board for ~250VDC.
YES
Change lamp driver with part # 1-468-798-13 AND modify the HV wire dressing. Does lamp light?
YES
DONE
NO
Change G1 Board.
NO
Replace R3027 on the C2 board with part # 1-216-809-11.