

## Author Feedback

- Readers who build my “Automatic Hold Device” (February 1989) using perforated board should make sure to ground pins 8 and 9 of CD4001 *IC* to assure stable operation of the project. These pins are not shown grounded in the schematic diagram. Readers who use the published etching-and-drilling guide to make a printed-circuit board or a board purchased from me need not be concerned about this because the trace to pins 8 and 9 of the IC goes to the ground trace in the pattern.

Anthony J. Caristi  
Waldwick, NJ