




# CALIFONE




**MODELS 3410C & 3430C**  
**CASSETTE PLAYER & RECORDER**

# SERVICE MANUAL

# WIRING DIAGRAM




# SCHEMATIC DIAGRAM



**MODEL 3410C**




# EXPLODED TRANSPORT




MODEL 3410C

# EXPLODED CASE




MODELS 3410C & 3430C

PC BOARD-REVERSE SIDE




MODELS 3410C & 3430C

# EXPLODED TRANSPORT




MODEL 3430C

# WIRING DIAGRAM



# SCHEMATIC DIAGRAM



# MODEL 3430C



