

**CD PLAYER CODES  
CODES DES LECTEURS  
DE DISQUE COMPACT**

CD Player Brand Marque	5-in-1 Code Code 5-en-1	CD Player Models Modèles
ADC	018	A-2080E, CD-1000E/2000E
Adcom	192	CD GCD-575, GTP-500II, GFB-800
Adcom	155	GCD-300
Adcom	234	GCD575
Aiwa	249	RC-T770F
Akai	156	700, CD43, others
Audio-Technica	170	AT-CD20
BSR	194	2020XR
BSR	134	X-1000
California Audio Lab	029	some models
Capetronic	237	some models
Carrera	194	CD-3300R
Carrera	394	CD-3400R
Carver	008	CD/Amp/Tuner AVR100, CT-17, CT-Seven, HR-752, RH-75
Carver	157	RH-74
Carver	179	TLM-3600
Casio	201	some models
Crown	122	some models
Curtis Mathes	201	Audio CX3125R
Denon	003	Unified: good for most models
Emerson	155	some models
Emerson	305	AD2575
Emerson	164	CD175R
Fisher	048	CA-854, CA-9025, REM-625/630/854/872/877, RS-881A/911A
Fisher	174	REM-815
Fisher	219	REM-949
Fisher	179	REM-991 (13-1248)
Fisher	088	Tuner/CD/Tape/ Amp Studio Standard REM-875 Tuner/CD/Tape/Phono/ Amp Studio Standard REM-885 Tuner/Tape/Phono/Amp Studio Standard REM-285
Genexxa	032	CD-5200
Genexxa	164	CD-5300 (42-8405)
Genexxa	305	CD-8001

CD Player Brand	5-in-1 Code	CD Player Models
Goldstar	030	CD/Amp/Tuner
Goldstar	394	GCD-MR1
Harman Kardon	060	HD300
Harman Kardon	173	AVR30, HD7450/7500/7500II/ 7600/7600II/7650, TL8500, TL8600
Harman Kardon	108	HD400, HD800, HD7400
Hitachi	155	DA-600B
Inkel	065	CD-8900
Inkel	061	CS-8970
JVC	072	CD AX-R87, XL-M403, XL-V330, XL-Z411
JVC	072	CD/Phono RX-5V, RX777VS, XL-Z444BK
Kenwood	190	CD DR-R4440, RC-P2010, RC-PM5520, RC-PM6620
Kenwood	077	CD/Amp/Tuner/Phono/Eq
Kenwood	338	CD/Tuner CA-R2, KCA-R1
Kenwood	337	CD/Tuner CA-R2, KCA-R1, KRC-810
Kenwood	048	DP-M4010, others
Kenwood	037	UD-3
Kenwood	028	Unified: good for most models
Kyocera	018	DA-102/510CX/610CX/710CX, R-861
Luxman	093	CD/Amp/Tuner/Phono R-114, RR-115, RR-117
Luxman	328	D-105U, D-107U
Luxman	035	DC-113
LXI	201	some models
Magnavox	157	650, CDB496BK01, MRB200BK01, RC100 AS405M3701, AS94183701
Magnavox	103	CDU-484
Marantz	157	CD-40, RC700-AV, RC-92SR
Marantz	373	RC-115S, RC-1157, RC-1159
Marantz	180	RMC-320
Marantz	128	Unified: RMC101
MCS	043	some models
MCS	345	CD/Tuner
MCS	201	Penney CD/Amp/Tuner
MGA	083	Rack System
Mission	157	DAD 7000
Mitsubishi	083	A-157, A-159, DE3100, DP309/DP409
NAD	299	5170
NAD	019	535

CD Player Brand	5-in-1 Code	CD Player Models
NEC	234	A-1300E, AVR-710, R-510
NEC	043	CD-650
Nikko	170	NCD-200R
Nikko	174	NCD-770R
NSM	157	CD-3101
Onkyo	102	Unified: TX-88
Onkyo	101	DX-310, DX-530, DX-C200, RC-AV20M
Onkyo	138	RC-128C
Onkyo	137	Unified: good for most models
Optimus	179	42-5015
Optimus	096	42-8402
Optimus	175	CD-1650 (42-5013)
Optimus	428	CD-1660 (42-5031)
Optimus	194	CD-2450 (42-5016)
Optimus	437	CD-1760 (42-5030), CD-6200 (42-5023, 42-5024)
Optimus	196	CD-2460 (42-5019)
Optimus	000	CD-6100 (42-5021)
Optimus	420	CD-6120 (42-5022)
Optimus	440	CD/Amp/Tuner System 600 (13-1247)
Optimus	037	System 620 (13-1251)
Panasonic	029	EUR64144, SL-PC362
Panasonic	303	SU-AV100
Penney	201	MCS CD/Amp/Tuner
Penney	043	MCS Series
Phillips	157	880, CDC-875, FR-50, FR-60, FR-70, RC-980/980FA
Phillips	103	LV-467
Pioneer	096	CU-PD007, CU-PD040, CU-SA001, CU-SA002
Pioneer	244	CU-X700, CU-XR003
Pioneer	032	Unified: good for most models
Proton	157	AC-300, AS-30R
Quasar	029	CD8989, EUR 64552
RCA	155	some models
RCA	346	CD/Amp/Tuner 100-10/15
RCA	053	Unified
Realistic	155	42-5004, 42-5007
Realistic	175	42-5013
Realistic	179	42-5014
Realistic	180	42-5020
Realistic	420	CD-6120 (42-5022)
Realistic	237	Modulaire 560
Rotel	157	RCD-855, RCD-955AX, RRT-4, RTC-850, RTC-950AX
SAE	157	IS-200, IS-300
Samsung w/Amp/Tuner		070K-660, K-660CD, K-760CD

<i>CD Player Brand</i>	<i>5-In-1 Code</i>	<i>CD Player Models</i>
Sansui	346	CD/Amp/Tuner RS-F8
Sansui	157	R-950AV
Sansui	305	RS-1065U
Sansui	148	Unified: good for most models
Sanyo	219	AVM 222RE, GXT 848U, GXT 888U, RB V7, 1770/2770
Sanyo	087	CD/Amp/Tuner DCX 686A, RB 100A, RB V8
Sanyo	179	CPM 900, RB 860/SS, RB710
Sanyo	349	RB LD5
Scott	164	DA1000, RS550
Scott	305	DA5001
Sears	201	CD/Amp/Tuner LXI Series
Sharp	262	CD-JX20XGY, CDX-3X
Sharp	037	DX-C3500/3510, RRMCG0078AFSA, SA-R55AV, SC-6900/6950
Sharp	180	DX-C5000
Sherwood	180	some models
Sherwood	065	AD-226R, AD-266R
Sherwood	114	CD/Amplifier RV-1340R, CD/Amplifier/Cassette GC-1285
Sherwood	061	Concert-13
Signature	108	200
Sony	397	CFD-770
Sony	185	RM-764, RM-E7, RM-P303, RMT-101/322A/J601/J722
Sony	000	Unified: good for most models
STS	018	SR100MK2
Sylvania	157	some models
Symphonic	183	several models
Teac	016	CD RC-4, CD/Amp/Tuner RC-200S
Teac	045	PD-600M, others
Teac	153	RC-307, others
Teac	180	RC-330
Teac	183	RC-410 some series
Teac	393	RC-410 some series
Teac	378	UR-200
Technics	029	EUR64110, RAK-SA301P, SA-330/937, SH-R51, SL-P3/P230/P300/P555/PS70, THX
Technics	207	EUR64754, SPL-5
Technics	303	SLPS-70
Techwood	363	some models
Theta Digital	103	some models
Toshiba	019	some models
Toshiba	299	RM-A210, XR-9057

<i>CD Player Brand</i>	<i>5-In-1 Code</i>	<i>CD Player Models</i>
Vector Research	394	VCD-628R
Victor	072	AV-707, DRE-1100
Wards	108	63796107
Yamaha	187	CD AVR750, AVX500, CX600/1000, DSPA1000, RX700U, VK31080
Yamaha	036	CD2, CDC705, CDX1030
Yamaha	170	CD700, RSD5, RS3
Yamaha	082	CD/Amp/Tuner/Phono AVC50, AVX100, AVX700

### AUDIO AMP/TUNER CODES CODES DES AMPLIS/TUNERS

<i>Audio Amp Tuner Brand</i>	<i>5-in-1 Code</i>	<i>Audio Amp/Tuner Models</i>
<i>Marque</i>	<i>Code 5-en-1</i>	<i>Modèles</i>
Aiwa	064	Amp/Tuner/Phono T300
Aiwa	158	RC-T004
Aiwa	125	Tuner/Tape/Phono TX-110
Carver	042	HR-772
Carver	189	RH-74
Carver	360	Tape B TDR-2400
Casio	195	some models
Clarinette	195	Amp/Tuner 125
Denon	004	Unified: good for most models
Fisher	042	Amp/Tuner REM-630, REM-854, REM-872, Amp/Tuner/Phono CA-854, CA-9025, RS-625/881A/911A
Fisher	360	Tuner/Tape 2 REM-991 (13-1248)
GE	181	11-110x Series
Goldstar	057	Unified: CS-7700
JVC	074	AX-R87, RX-5V, RX-500, RX-777VS, RX-1010V, XL-Z444BK
Kenwood	186	UD-3
Kenwood	027	Unified: good for most models
Luxman	166	Unified: RTP-117
LXI	181	some models
Magnavox	189	AS405M3701, AS94183701, MBR150, MBR200RK01

<i>Audio Amp/Tuner Brand</i>	<i>5-In-1 Code</i>	<i>Audio/Amp Tuner Models</i>
Marantz	038	Unified: good for most models
Marantz	189	PM-700, RC-92SR, TA-170AV
MCS w/Tape	044	some models
Modulaire	195	Amp/Tuner 510 (13-1241), Amp/Tuner/CD 560 (13-1242)
NAD	320	1600/1700/7000/7100/7400/7600
Onkyo	144	Unified: RC-47
Onkyo	135	Unified: Tuner/Amp/Tape 1
Optimus	177	16-9601 STAV-3100 (31-3017) STAV-3200 (31-3020)
Optimus	186	System 620 (13-1251)
Panasonic	039	EUR64144, SA-H51, SG-H30
Panasonic	389	RX-DS660
Penney w/Tape	044	some models
Philips	189	DFA-980, FR-50, FR-60, FR-70, RC-488CDV, RC-980
Pioneer	080	Unified: good for most models
Pioneer	014	Unified Tuner
Quasar	039	CS 27
RCA	054	Unified: good for most models
Realistic	181	13-1233, 13-1234, 13-1235 Rack System 1020 (13-1243) Rack System 1220 (13-1244)
Realistic	182	13-1236, Modulaire 570 (13-1246), System 320 (13-1238)
Realistic	178	16-1285
Realistic	001	31-1130
Realistic	025	31-3016
Realistic	163	Amp/Tuner 13-8100
Realistic	195	Amp/Tuner Modulaire 510 (13-1241), Amp/Tuner/CD Modulaire 560 (13-1242)
Sansui	189	R-950AV
Schneider	364	some models
Scott	163	Amp/Tuner RS500, others
Sharp	186	CD-U10H(GY), RS-6900, SA-R55AV, SC-6900/6950, SGF800, RRMCG0063AFSA, RRMCG0078AFSA
Sony	158	Unified: Amp/Tuner/Phono
Symphonic	182	CD System F-20
Teac	163	Amp/Tuner AG-55

<b>Audio Amp/ Tuner Brand</b>	<b>5-in-1 Code</b>	<b>Audio/Amp Tuner Models</b>
Technics	039	Amp/Tuner/Phono/Deck EUR64110, SA-937/GX100/R330, THX
Techwood	364	some models
Victor	074	AV707, DRE-1100
Yamaha	176	Amp/Tuner/Tape/Phono AVX500, CX600/1000, DSPA1000, RX700U Amp/Tuner/Tape/Phono/EQ AVR750, RXV850/1050
Yamaha	186	Tuner/Tape AST10, YSTC11
Yorx	195	Grandeur 2116

### AUDIO AMPLIFIER CODES CODES DES AMPLIFICATEURS AUDIO

<b>Audio/ Amplifier Brand Marque</b>	<b>5-in-1 Code Code 5-en-1</b>	<b>Audio Amplifier Models Modèles</b>
Denon	160	Unified: good for most models
Kenwood	297	AV/Surround SS-97
Luxman	165	Unified: RTP-117
Marantz	321	RC-1157, RS-3555, RS-3559
Optimus	395	31-3018, 31-3021
Philips	269	DFA980, RC488CDV, RC980
Pioneer	300	CU-VSX014/015/018, VSX-3600, VSX-7500X
Pioneer	013	Unified: Amp/Surround A
Sansui	321	RS-1260, RS-1380, RS-F16, RZ-7500AV, RZ-9500AV
Soundesign	211	998

### HOME AUTOMATION CODES CODES DES SYSTÈMES AUTOMATIQUES MÉNAGERS

<b>Home Automation Brand Marque</b>	<b>5-in-1 Code Code 5-en-1</b>	<b>Home Automation Models Modèles</b>
GE X10 Homeminder	240	
One-For-All X10 Security System	167	
Radio Shack Plug 'n Power	240	
Security System One-For-All/X10	167	
Universal X10 Security System	167	
X10 One-For-All Security System	167	

**CABLE CONVERTER CODES  
CODES DES CONVERTISSEURS  
DE TÉLÉ PAR CÂBLE**

Cable Converter Brand Marque	5-in-1 Code Code 5-en-1	Cable Converter Models Modèles
ABC	011	J400L
ABC	007	O56L
ABC	013	RCU-T 5503A
ABC	017	V2 SA8500
Antronix	207	RC-700
Archer	022	15-1285, some serial numbers
Archer	039	15-1285, some serial numbers
Archer	207	15-1285A
Archer	153	15-1287
Cable Star	056	some models
Century	153	CC7500
Citizen	153	JSB 178 XK
Colour Voice	025	2500
Colour Voice	031	2700
Comtronics	060	Eagle
Comtronics	040	Eagle EUSC-2000
Eagle Comtronics	040	EUSC-2000
Eastern	002	IRT001/IRT10, IRT200
Electricord	078	V-7200A
GC Electronics	056	32-3585 (Normal Mode)
Gemini	057	AD6000
Gemini	070	AD6000 (older)
Gemini	242	AD6000, others
Gemini	015	AD7500
General Instruments	011	LCC 58
Hamlin	034	some models
Hamlin	020	CRP6, CRP7, CRP8, CRP83, Ham-7
Hamlin	259	CRP9
Hamlin	273	CRP9
Hamlin	009	CRX, RCP, RCPX
Hitachi	011	CLU-600PR, CLU-950GR, VT-441A
Jasco	153	some models

Cable Conv. Brand	5-In-1 Code	Cable Converter Models
Jerrold	011	400, J400L
Jerrold	024	440, others
Jerrold	014	450, SCR I
Jerrold	003	550, 550D, MRC550D, Impulse 7000
		SRC II, Starcom VI
Jerrold	015	Starcom CS
Jerrold	047	Starcom V
Jerrold	098	Starcom XT
Macom	033	some models
Magnavox	027	some models
Magnavox	069	some models
Memorex	000	some models
Movie Time	078	some models
Movie Time	156	IRKT-040
Northcoast	314	Excel
NSC	063	some models
NSC	156	305, others
Oak	248	Micro 550
Oak	007	RCU-400
Oak	019	Sigma, Sigma 2000
Panasonic	021	most models
Panasonic	107	TZ-PC1403P, TZ-PR170
Paragon	000	some models
Philips	060	some models
Philips	027	some models
Philips	029	some models
Philips	030	some models
Philips	031	CT3000, CVS2700
Philips	290	CV2600
Philips	025	CVS2500
Pioneer	144	BR60,70,80,81,82,82C, BA5000N
Pioneer	023	BR50
Pulsar	000	CP4
RCA	021	some models
Realistic	207	16-1283
Regal	279	CR83V-3/4
Regal	020	CRP83
Regal	259	CRP9
Regal	273	RC83-3
Regency	002	IRT001/IRT10, IRT200
Rembrandt	070	VA071R
RK	306	some models
Samsung	144	some models
Samsung	040	CTC-7500AE

Cable Conv. Brand	5-in-1 Code	Cable Converter Models
Scientific Atlanta	008	6700-075
Scientific Atlanta	017	8550-075
Scientific Atlanta	008	8550-175/475, 8580
Scientific Atlanta	277	8600
Signal	040	SL-1000
Signature	011	15298
SL Marx	040	SL 78R
Sprucer	021	some models
Sprucer	307	TZ-KC200/KC3002N/KR200/KR300
Starcom	015	CS
Starcom	047	V
Starcom	003	VI
Starcom	098	XT
Stargate	040	2000, EVC
Stargate	015	2001, 550XL
TeleCaption	221	4000
Texscan	096	Ultra
Tocom	013	55 Plus A-type
Tocom	059	55 Plus B-type
Tocom	012	RC300, RC700
Toshiba	000	CT-9491
Unika	207	702, STV-140
Unika	153	MR75, VC750
Unika	022	RC-60
United Artists	007	some models
United Cable	003	JSRCII
Universal	153	some VX Series models
Universal	078	Stereo Converter V-7472B
Universal	056	Stereo Decoder/Converter
Universal	077	V-1000
Universal	207	V-7640
Universal	022	VX Series V-6060
Universal	039	VX Series, some models
Universal	191	VX-V7072
Viewstar	027	some models
Viewstar	060	some models
Viewstar	063	some models
Viewstar	111	some models
Viewstar	289	2520
Zenith	054	Z-TAC 124-31 (older)
Zenith	000	Z-TAC

**TELEVISION CODES  
CODES DES TÉLÉVISEURS**

TV Brand Marque	5-in-1 Code Code 5-en-1	TV Models Modèles
A-Mark	003	MC2134 AX
Akal	098	RC-V618
Anam	180	1408RMA, 1608RMA
Anam National	055	1400R, 1600RM, 2000R, L2PH
AOC	019	several models
AOC	030	several models
AOC	268	some older models
AOC	052	C3622RA, C9820R
AOC	003	RT-1200
Archer	003	15-8287
Audiovox	003	some models
Candle	046	JCTV1530, JCTV3150
Candle	186	JCTV1534/3153/3155
Candle	030	JCTV1548
Candle	056	JCTV3400
Capehart	052	some models
Citizen	046	JCTV1531/3153/3200/3201/ 3202/3602/3603
Citizen	186	JCTV1532,33,90/3102,51,54,56/ 3203,05/3305
Citizen	056	JCTV1549/3049/3058/3157/ 3207/3230
Citizen	039	JCTV1570/3120
Citizen	030	JCTV1590/3080
Citizen	060	JCTV3208/3401
Concerto	056	JCTV1541
Contec	185	MF-1351, MF-1951
Contec	180	MSFR-1971, MSFR-2572
Craig	180	several models
Crown	039	several models
Curtis Mathes	060	B1959RW, B2050RW, B2571RW, B2572RL
Curtis Mathes	030	B2774RL, B2786RL
Curtis Mathes	039	TC-2500RL
CXC	180	MS199R
Daewoo	019	CT-1490/2695, DCB-2007FAW/ 408FAW, TB-1411FW
Daewoo	039	TCB-1488VW
Daytron	039	some models
DynaTech	049	some models
Electrohome	039	164-06, 164-07, CT-880, CT-890

TV Brand	5-in-1 Code	TV Models
Emerson	180	ECR1350/2100, MS198RA/ 199R/250RA/2580RD/2700RD TS4451D
Emerson	177	ECR137, ECR138, ECR139, ECR212, ECR214, ECR218
Emerson	185	ECR162
Emerson	039	ECR210
Emerson	183	ECR215D
Emerson	178	ECR221, M-13/20/195-R, MS-251DA/251R/30RB/30RBK
Emerson	179	M20RC
Emerson	236	M2250RDA, TC1360/1960/ 2551RD, TS4451/A, VT0950/ VT0950N
Emerson	181	MS198R, MS250R
Emerson	282	TC1316RN
Emerson	280	TC1933
Emerson	270	TS4650D/A/B
Envision	030	EM9163
Fisher	154	PC202W, PC225, PC360, TT810, others
Fisher	159	PC340, others
Fortress	093	RTV910
Fujitsu	179	some models
Funai	179	several models
Funai	180	several models
Futuretech	180	19186 P
GE	021	several models
GE	027	several models
GE	029	several models
GE	174	some older models
GE	051	40HP5000K, 40PW3000K, many others
GE	178	8-1340, 8-1341, 8-1445
GE	055	8-2549/2550/2552/2562/2564/ 2569, 40FP4000K, others
GE	047	GE26GC640, GE82040, 26GT640, 13GP-410F/411F/ 413F, others
GE	282	Spacemaker 7-7690
Goldstar	056	some models
Goldstar	019	CNR-26250/2688/4525
Goldstar	002	CNR-2802/3300
Goldstar	001	CNR-4488/4489/6128/6688/ 6689/9988/9989
Goldstar	106	CNR-842
Goldstar	178	FS-192H, others
Goldstar	039	KMC, 63750832
Hallmark	178	some models
Hitachi	227	several models
Hitachi	151	CLU-150/151/174/176/183A/ 201/720

TV Brand	Code	TV Models
Hitachi	039	CLU-160, CLU-600, VT-RMS730A, many others
Hitachi	056	CLU-171
Hitachi	038	CLU-220, others
Hitachi	145	CLU-253B/330UC/520IR/ 600PR/609/611PR/730/950GR CLU-2xx most models
Hitachi	095	CMT-2083
Hitachi	097	TV/VCR CLU-270
Infinity	054	Reference Standard TV
JBL	054	B T405 AD NF, R0319A-AG02, TC-1
JVC	053	AV-2556/2649S/2749S, AVS-290M, AX-R87, C1327, CT-79, HR-5500U, PQ10544, PQ10544B, RM-C413/C416/ C41B/C422/S20, RX-1010V, RX-5V, RX-777VS
JVC	160	CT-813, CT-810ME, many others
JVC	069	HR-D5000EK, HR-D950EK, PQ10544
Kenwood	030	KV-D957S, RC-126, RC-70
Kloss	046	T-1
Kloss Novabeam	024	some models
KMC	106	CNR-842
KTV	280	13TEC, 19TEC
KTV	180	19LXC, RC-800
KTV	039	KCT 1955
Logik	016	LPA1950RS
Luxman	056	TV Stereo Tuner
LXI	148	2, others
LXI	047	274.xxxxx
LXI	154	564.xxxxx older models, LXI 1
LXI	054	626.xxxxx
LXI	156	older models
Magnavox	020	several models
Magnavox	024	several models
Magnavox	028	several models
Magnavox	030	several models
Magnavox	186	several models
Magnavox	187	several models
Magnavox	096	PS4956, RF 4352, RS4956PE05
Magnavox	054	RC 100, RH4560, RJ4049/ 6050/8510/8540/8550, RK8548
Marantz	030	RC 700AV054 MarantzRMC25
Memorex	178	16-254, 16-263, 16-280
Memorex	016	some models
Memorex	154	TC-193 (16-229)

<b>TV Brand</b>	<b>5-in-1 Code</b>	<b>TV Models</b>
MGA	019	several models
MGA	030	several models
MGA	155	several models
MGA	178	several models
MGA	150	CS-205R, Rack System
Mitsubishi	178	CK 2560R, CS-1954-R CS-2011-R, other older models
Mitsubishi	155	CS-1997UC, other older models
Mitsubishi	019	DA-1000, TX-102R, VS-522R, VS-524R
Mitsubishi	098	HS-330UR
Mitsubishi	150	Unified: good for most models
MTC	019	several models
MTC	049	several models
MTC	030	MTC144R/227R
MTC	060	MTV1440R/2050R/2080S/ 2260R/2600R
MTC	056	MTV207R
Mullitech	217	MC-1910R
NAD	156	MR-13
NAD	166	MR-45
NEC	019	RB-926
NEC	036	RD-1601E/81E
NEC	056	RD104-E, others
NEC	030	Unified: good for most models
Onwa	180	some models
Optonica	165	G0504GE
Optonica	093	G0609CESA
Panasonic	051	CKT-20858, CT-9053, CTH-2570R, CTJ-2770R, CTM-2066S
Panasonic	055	Electrotune TNQ-1459/1614 /2605, CT-9062/9082/9092
Panasonic	054	EUR-50323
Panasonic	051	EUR50423, EUR64144, EUR64595, PV-M2028/M2730 TNQ2601, TNQ2603, VSQS0727
Penney	030	685-4507, 6088, others
Penney	021	several models
Penney	135	some older models
Penney	060	2139/2140/2161/2516/4161/ 4162/2147/2517
Penney	047	604025
Penney	149	685-2065-00
Penney	039	685-2083
Penney	019	685-2220
Penney	018	685-2501J, others
Philco	019	several models
Philco	020	several models

<b>TV Brand</b>	<b>5-in-1 Code</b>	<b>TV Models</b>
Philco	028	several models
Philco	030	several models
Philco	054	several models
Philco	186	several models
Philco	187	several models
Philips	000	some models
Philips	054	FR-80, RC-488CDV, VR8595, others
Pioneer	038	some older models
Pioneer	166	Unified: good for most models
Portland	019	some models
Portland	039	DCB2105R
Proton	052	P600T, P619
Proton	178	P601T, P619A, P625, VT-210, VT-290
Proton	039	P613, P619S
Pulsar	017	CP4
Quasar	055	several models
Quasar	051	TNQ1404, TT5969WW, TV-TL9960YP, others
Radio Shack	032	16-230
Radio Shack	039	16-231, 16-234
Radio Shack	165	16-232, 16-233, 16-236, 16-250, 16-251, 16-260
Radio Shack	178	16,255, 16-288
Radio Shack	180	16-252, 16-253, 16-262, 16-246
RCA	029	19ECxxxx series, some models
RCA	019	some models
RCA	254	some models
RCA	135	some older models
RCA	174	some older models
RCA	018	ColorTrak 2000, FFR-488WR/ 498WR/530SR ColorTrak FJR-478WR/479WR/ 480WR/484WR/488WR/530PR FKR468WR
RCA	038	PGR-100WR
RCA	047	Unified: good for most models
Realistic	154	16-229, 16-261
Sampo	030	several models
Sampo	052	KA-1918
Samsung	039	some models
Samsung	030	C3302CA
Samsung	060	CT-1483, TC-25406
Samsung	019	CT-14845, CT-2875, SVP-450
Samsung	032	CT-1495
Samsung	056	TM-151, others
Sanyo	146	several models
Sanyo	159	several models
Sanyo	154	DS25830, others

<b>TV Brand</b>	<b>Code</b>	<b>TV Models</b>
Scott	179	HTS220
Scott	180	HTS2700
Scott	236	HTS2960DG/HTS3075D/ HTS3261DG
Scott	039	SP14, SP16, SP17
Sears	148	some models
Sears	047	274.xxxxx
Sears	156	562.xxxxx, 564.53482950
Sears	154	564.42561751, 564.53482950, SR2000 some models, SR3000
Sears	178	564.53482950
Sears	146	564.xxxxx older models, SR1000, SR2000 some models
Sears	159	564.xxxxx, some models
Sears	056	580.xxxxx
Sears	179	934.xxxxx
Sears	149	Channel Touch 3
Sharp	039	several models
Sharp	093	19RV629P, 20RV69, 25RV79, 25SB620, G0711CESA RRMCG0724CESA
Sharp	165	25NC168, G0453GE, G0504GE
Sharp	153	RRMCG0156CESA, RRMCG0170CESA
Signature	016	2000
Sony	000	Unified: good for most models
Sony	011	some older models
Sony	080	some older models
Sony	111	RM-703, RM-712, RM-714
Soundesign	178	several models
Soundesign	180	some models
Soundesign	186	8182, others
Spectricon	003	2000VAR
Sylvania	020	several models
Sylvania	024	several models
Sylvania	028	several models
Sylvania	030	several models
Sylvania	186	several models
Sylvania	187	several models
Sylvania	054	RKE198SL05, RLK330 WA01, RNF922PE
Tatung	049	13CFB, 19CFB
Tatung	055	1900CM, RM-F1602
Technics	051	RAK-SA301P, SA-937, SA-R330, THX
Yamaha	019	RS-V9
Yamaha	030	YV810
Zenith	016	several models
Zenith	017	Unified: good for most models
Zonda	003	CT-1340R, CT-1940R

## VCR CODES CODES DES MAGNETOSCOPES

VCR Brand Marque	5-in-1 Code Code 5-en-1	VCR Models Modèles
Aiwa	000	AXR 002
Akai	041	several models
Akai	049	several models
Akai	242	VS-606, others
Akai	053	VS-616U, others
Akai	061	VS-61U
Broksonic	121	RC-09
Broksonic	211	VHSA-6687SL
Broksonic	184	VHSA-6687TSLC, VHSA-6741TC
Canon	167	A-10, WL-100, WL-E80
Canon	035	Portable, WL-800
Canon	102	WL-800 Search, Digital Functions
Capehart	020	VHS-D6500
Craig	240	PT720
Craig	047	PT740
Craig	271	PV7260
Curtis Mathes	035	BV780, CV730/735/745/750/758
Daewoo	020	32-DB, 52-DA, VHS-30DA
Daewoo	278	DVR-5038N
Daewoo	087	VCR-60LA, others
Daewoo	045	VCR-81HA, others
Daytron	020	DVR-7232N, VCR-32DAU
Dynatech	000	VR30
Emerson	061	ECR870, VCR910
Emerson	209	SVR115, VCR592, VCR873, VCR952
Emerson	211	VCR754, VCR872, VCS966A, VCS977A
Emerson	121	VCR755, VCR765, VCR875, VCR953(B)
Emerson	184	VCR765, VCR885N, VCR964, VCR964N
Emerson	208	VCR850, VCR870, VCS955
Emerson	212	VCR862, VCR953(A)
Emerson	000	VCR870

VCR Brand	Code	VCR Models
Emerson	068	VCR874, others
Emerson	088	VCR951A, VCS955A
Emerson	037	VCR988
Emerson	036	VCS966H, VCS977, others
Emerson	294	VT0950/VT0950N
Emerson	002	VT4490/D
Fisher	104	CA-9025, RVR-4502, RVR-7600
Fisher	047	FVH-906/920/930/940/950/960/ 4000/4100/4200
Fisher	054	FVH-715/721/725/805, others
Fisher	066	FVH-825, others
Funai	000	some models
GE	065	1VCR3014W
GE	035	1VCR5014X, 1VCR6011X, 1VCR6018X, 40HP5000K, 9-7100/7110/7120 9-7135/7400/7500/7785, EW62X0265/0291, ICVT625, VSQS0649
GE	060	VG Series, others
Go Video	232	GV 2000 VCR1
Go Video	279	GV 2000 VCR2
Goldstar	018	several models
Goldstar	038	several models
Goldstar	037	GHV- series
Harman Kardon	038	VCD2000, 4000
Hitachi	000	some models
Hitachi	041	some models
Hitachi	042	CLU-270, CLU-330UC, CLU-340, CLU-600PR, CLU-950GR, VT-251E, VT-3000, VT-xxA Series, VT-xxxxA Series, others
Hitachi	292	VT-15A
Hitachi	105	VT-19A/86A/630A/1320A/ 1450A/1570A/2060A/3000
Hitachi	166	VT-551E/F430A/RM2600A/ RM330A/RM441A/S730A
Hitachi	065	VT-9710A, VT-TU68A
JCL	035	TC-1
Jensen	041	AVS-4400, AVS-4500, AVS-6200
JVC	067	AVS-290M, AX-R87, HR-D5000EK/D57U/D660U, HR-SxxxxU Series PQ10544, RM-413, RM-440, RM-706, RX-1010V, RX-5V, RX-777VS
JVC	008	HR-D5000EK, HR-S5000U, HR-S8000U, PQ10544, RX-1010V

VCR Brand	Code	VCR Models
JVC	206	HR-D840U/D850U/S5500U, PQ10842
JVC	041	HR-DxxxU series, most models
Kenwood	046	some models
Kenwood	041	KV-915
Kenwood	067	KV-905
Lloyd	000	LRC 828
Logik	072	LVA 2201
LXI	037	some models
Magnavox	035	good for most models
Magnavox	081	AV5635, RC100, VR2032, VR2040
Magnavox	149	PIP
Marantz	081	PM-700, RMC-170AV
Marantz	035	VR-9642AT101
Marta	037	MVR-1000, others
MEI	035	several models
Memorex	046	16-529, 16-530, 16-621
Memorex	039	some models
Memorex	048	Mdl 100 (16-618), 16-531, 16-622
Memorex	000	Mdl 14 (16-406), Mdl 18 (16-410), Mdl 19 (16-411), Mdl 29 (16-517), SM-25
Memorex	104	Mdl 49 (16-619), Mdl 50 (16-620), Mdl 53 (16-623) Mdl 85 (16-523), Mdl 87 (16-525), Mdl 88 (16-526)
Memorex	299	Mdl 800 (16-654)
Memorex	037	Mdl 20 (16-412), Mdl 86 (16-524), SM-15, 16-408
Memorex	268	MovieCorder 153 (16-854)
Memorex	035	SM-260, 16-705
Memorex	047	SM-30, SM-100, SM-200, SM-250, SM-450, SM-500
MGA	043	HS-3471-UR, others
MGA	061	Rack system
Minolta	042	HiFi MV405/605/705
Minolta	105	HiFi MV405/605/705
Mitsubishi	242	several models
Mitsubishi	061	DA-1000, HS-330UR, others
Mitsubishi	214	HS-302U, HS-310U, RM-300U
Mitsubishi	173	HS-U51, U52, U53, many others
Mitsubishi	043	Unified: good for most models
MTC	000	most models
MTC	240	MCR218S
Multitech	000	MV-075, MV-080
Multitech	072	MV289

VCR Brand	Code	VCR Models
NEC	050	some models
NEC	067	831EU
NEC	038	A-1300E, AVR-710, CT-2062A, DS-8000U, N955U, PJ-52705
NEC	040	AV-210, AV-260, AV-300 PRO, DX-2000U, DX-5000U, N965U
NEC	038	PL-4650PB, R-510, RB-33P/34P/53K/959/D10, RC-1030E
NEC	041	RB-83EP, others
Optonica	048	27NL20BK, others
Optonica	062	G0609CESA
Panasonic	035	good for most models
Panasonic	254	some models
Panasonic	102	AG-1830
Panasonic	077	PV-1170
Penney	035	2291, 2292, 2301, 4508, 6182, 6184, 686-5038
Penney	240	6585
Penney	038	685-4507, 6088, others
Penney	040	686-6085
Penney	042	967-0049
Pentax	042	Portable
Pentax	105	Portable
Pentax	065	PV R020A
Philco	035	7091400520, 7091400670, 7091400970
Philips	035	488CDV, 6705, RC980, VR6895
Philips	081	FR70, VR6595, RC488CDV, many others
Philips	062	VR6540, VR6640
Pilot	037	VCR905
Pioneer	067	Unified: CU-AV001
Portland	020	VCR-32DAU
Pulsar	039	CP4
Quartz	046	53296, 53491
Quasar	035	good for most models
RCA	077	some models
RCA	035	187687
RCA	202	F31225SB, System Link, VR 675HF
RCA	065	VGP170
RCA	042	VKT326, VJT425
RCA	105	VKT326, VJT425, VJT700
RCA	149	VMT-285/285A/295/296/297/298/385/385A/389 VPT289, VPT290 series, VPT390 series, VPT595
RCA	060	Unified: good for most models

VCR Brand	Code	VCR Models
Realistic	066	16-503
Realistic	047	16-506, 16-511, 16-512, 16-513, 16-515, 16-516, 16-518, 16-613, 16-614, 16-615, 16-652
Realistic	037	16-507
Realistic	000	16-404, 16-508, 16-510, 16-519, 16-522, 16-703, 16-704
Realistic	240	16-514
Realistic	104	16-520, 16-521, 16-617
Realistic	046	16-600, 16-601
Realistic	062	16-610, 16-700
Realistic	048	16-611, 16-612, 16-616, 16-653, 16-701, 16-702
Realistic	035	16-651
Ricoh	034	R-860
Samsung	240	most models, SV- Series
Samsung	053	RMC-290T
Samsung	051	SV-84S, others
Samsung	045	SV-909HB
Sansui	041	RV-9
Sansui	271	S-V7
Sansui	067	SV-R9000
Sanyo	047	some models
Sanyo	046	Beta, VHR1900, VHR2700, VHR2900, others
Sanyo	268	SCR04
Sanyo	104	VHR9280
Scott	184	HTS2960DG/HTS3075D/HTS3261DG
Scott	121	SVR122, SVR160
Scott	212	SVR120
Scott	210	SVR240
Sears	054	143.xxxxx, some models
Sears	066	143.xxxxx, some models
Sears	104	564.53482950
Sears	047	564.xxxxx, most models
Sears	046	564.xxxxx, some models
Sears	037	580.xxxxx
Sears	035	626.54461850
Sears	042	934.xxxxx, MTS, SR2000 Series, SR3000 Series
Sears	105	LXI, SR-1000/2000/3000 series
Sharp	048	several models
Sharp	062	Optonica G0609CESA, G0711CESA, others
Shintom	072	VCR/4010N/4020N/4530N/550
Sony	033	Beta #1, Betamax, Super Beta Theater, VHS #1, others
Sony	034	Beta #2, Betamax, VHS #2, Video 8, Video Camera

VCR Brand	Code	VCR Models
Wards	149	63650870
Wards	047	63651516, 63682977, 63734845, 63780049
Wards	062	JSJ10551, RRMCG0038GESA
Wards	240	NR110, 63687456
Wards	000	Signature 2000 JFA-12490B, others
Yamaha	041	some models
Yamaha	038	RS-V9
Zenith	033	Beta #1
Zenith	034	Beta #2
Zenith	039	Unified: good for most models



## VIDEO ACCESSORY CODES CODES DES ACCESSOIRES VIDEO

Video Ass. Brand Marque	5-In-1 Code Code 5-en-1	Video Ass. Models Modèles
Jebsee A-B Switch	160 AB-27RS	
Radio Shack A-B Switch	160 (15-1957)	
TeleCaption	171 3000, II	

## SATELLITE RECEIVER CODES CODES DES RÉCEPTEURS DE SATELLITES

Satellite Rec. Brand Marque	5-In-1 Code Code 5-en-1	Satellite Receiver Models Modèles
Amplica	072 CSR-300, others	
Birdview	045 2020 MIR	
Birdview	079 IR AT 20/20	
BSR	095 SX-2010, SX-2020	
C Itoh	164 Citation	
Capetronics	095 2010, 2020	
Channel Master	257 6441M	
Channel Master	212 6442	
Channel Master	018 CM 6144	
Chaparral	053 Cheyenne, Sierra, Sierra II, Sierra III	
Chaparral	209 Monterey	
Curtis Mathes	072 MSR330	
Drake	064 6000	
Drake	245 RCU2400	
Drake	062 RCU1	
Drake	149 RT240	
Drake	066 RT240A Type 1	
Drake	150 RT240A Type 2	
DX Antenna	065 DX-700	
DX Antenna	041 DX-800	
Echostar	280 310/410, SRD-5000	
Echostar	159 4000	
Echostar	269 5000	
Echostar	312 SR-500, SR-520, SR-55	
Echostar	148 SRD-4000	
Fujitsu General	186 Videocipher II FSR-4000, FSR-4500	

Satellite Rec. Brand	5-In-1 Code	Satellite Receiver Models
General Instruments	071	IRC-2750R
General Instruments	038	RCU-2600R
General Instruments	050	Video Cipher II
Hytek	095	SRX-500
Janeil	152	BCR 5000N
Jerrold	036	Starcom V
Luxor	083	some models
Macom	018	some models
Macom	166	RCU-H11
Macom	061	T-1
Macom	050	Video Cipher II 2100E, others
Memorex	269	SR-2014 (16-2511)
MTI	229	28 IR
MTI	230	28 IR
Norsat	165	some models
Norsat	004	JR300
Panasonic	152	RMC-2000A
Philips	200	RC488CDV, RC980FA
Prosat	158	3901
Realistic	052	16-2507
Realistic	051	SR-2010
Scientific Atlanta	234	Homesat 900
STS	041	MBS LSR
STS	037	MBS SR
STS	210	SR100, SR100MK2
STS	190	SR110
Super Guide	311	SP1000
Toshiba	061	some models
Toshiba	082	CT-9240
Uniden	076	7000 UST-670
Uniden	052	9000 UST-699
Uniden	296	UST-4800r
Uniden	238	UST-4400r
Uniden	074	UST-9900r
Video Cipher II	050	some models
Zenith	061	some models
Zenith	064	6000

## VIDEO DISC CODES CODES DES LECTEURS DE VIDÉODISQUE

Video Disk Brand Marque	5-In-1 Code Code 5-en-1	Video Disk Models Modèles
Alwa	203 TX200	
Carver	064 RH 74	
Denon	172 AVC-1000/1000G, AVC-3000, AVR-1010, LA-3000, RC-139	
Funai	203 LD/CD/CDV TX200	
Magnavox	241 some models	
Magnavox	064 MRB200BK01, RC100	
Marantz	064 RC-700AV, RC-92SR	
Mitsubishi	059 M-RV7010	
NAD	059 MR-45	
Panasonic	204 LX-1000, SU-AV100, VEQ1185, VEQ1237	
Philips	064 CLD-488, FR-50, FR-60, FR-70, RC-980	
Pioneer	059 Unified: LD/CD	
RCA	128 Selectavision	
Realistic	203 LD/CD/CDV Player 16-302	
Sharp	001 CD/CDV/LD Player	
Sharp	237 MV-K70X	
Sony	201 CD-CDV-LD Player MDP-200, RM-689/764/P1000/P303, RM-U211	
Yamaha	237 CDV-1200	
Yamaha	217 LD AVR750, AVX500/700, Karaoke CDV-1200K, DSPA1000, VK31080	