FREQUENCY

LONG DURATION TIMER



SELECT R1C1, R2C2, R3C3 AND R4C4 TO GIVE DESIRED DELAY PER STAGE. DELAY = R×C. TOTAL DELAY = SUM OF ALL STAGES. LED TURNS OFF AFTER TIME DELAY AND TURNS ON AGAIN.